





* Read and understand the Owner's Manual before Maintenance the brush cutter.


Cutting attachment




Spark Plug





Engine Oil



Prolonged storage



Air Cleaner Element



Maintenance Schedule

	Before each use	First month or 10 Hours	Every 3 months or 25 Hours	Every 6 months or 50 Hours	Every year or 30 Hours	Every year or 100 Hours	Every 2 years or 300 Hours
Air cleaner	Check	Change	Change	Change	Change	Change	Change
Engine oil	Check	Change	Change	Change	Change	Change	Change
Throttle cable	Check	Check	Check	Check	Check	Check	Check
Gear case	Check	Check	Check	Check	Check	Check	Check
Grass deflector	Check	Check	Check	Check	Check	Check	Check
Cutting attachment	Check	Check	Check	Check	Check	Check	Check
Nuts, bolts, fasteners	Check	Check	Check	Check	Check	Check	Check
Carrying harness	Check	Check	Check	Check	Check	Check	Check
Engine oil	Check	Change	Change	Change	Change	Change	Change
Air cleaner	Check	Change	Change	Change	Change	Change	Change
Engine oil	Check	Change	Change	Change	Change	Change	Change
Engine coolingfans	Check	Check	Check	Check	Check	Check	Check
Gear case	Check	Check	Check	Check	Check	Check	Check
Spark plug	Check	Check	Check	Check	Check	Check	Check
Fuel tank	Check	Check	Check	Check	Check	Check	Check
Fuel filter	Check	Check	Check	Check	Check	Check	Check
Air cleaner	Check	Change	Change	Change	Change	Change	Change